

CLF-580 Lens Replacement Foot

fits Canon EF800mm f5.6L IS

**may fit other lenses not listed*

SKU: CLF-580



CLF-580 pictured

A GREAT
alternative to a
separate lens plate—
simply remove your
existing stock foot
and install!

About NSN Replacement Feet

NSN's replacement feet for popular telephoto lenses are made of super strong 6060 aluminum and precision designed to be strong, lightweight and a perfect fit. The integrated arca-swiss compatible design will fit any arca-swiss style quick release clamp found on popular tripod support heads such as Wimberley®, Really Right Stuff, Kirk, 4th Generation Designs, Jobu Design, Custom Brackets, Benro®, Induro®, Arca-swiss and many others.

INSTALLATION INSTRUCTIONS

- 1** With supplied hex key wrench remove original lens foot from the rotating collar of the lens. Set 4 screws aside.
- 2** Carefully line up the 4 holes of the NSN replacement foot with the 4 holes in the lens foot mount on the rotating collar of the lens.
- 3** Re-install each of the 4 original screws, one at a time, leaving them each only partially tightened.
- 4** With the 4 screws partially tightened, check the exact position of the replacement foot to ensure it is properly aligned, then tighten each screw thoroughly.

The two small screws on the bottom of the foot are “safety stop” screws, which can prevent the foot from sliding out of a partially-loose quick-release clamp. These can also be removed, per user preference, with included small hex-key wrench. Check all screws initially, and then again periodically, to ensure they are tight. Use of blue Loctite® threadlocker or other thread-locking adhesive is optional.

If you have any questions about installation please contact our friendly customer service—we are more than happy to assist!

Call 888-667-0559 or email retail@naturescapes.net
21009 Gunpowder Road, Manchester, Maryland 21102 USA
Visit our website at www.NatureScapes.net