



run&gunBags vs. cameras

run&gunBag Medium
run&gunBag Large
run&gunBag-XL

. _ Sony			
. . _ PXW-Z100	X	X	
. . _ PXW-X70	X		
. . _ PXW-X500			X
. . _ PXW-X200	X	X	
. . _ PXW-X180	X	X	
. . _ PXW-X160	X	X	
. . _ PXW-FS7		X	X
. . _ PMW-F55		X	X
. . _ PMW-F5		X	X
. . _ PMW-EX1R	X	X	
. . _ PMW-500			X
. . _ PMW-400			X
. . _ PMW-350L			X
. . _ PMW-350K			X
. . _ PMW-320L			X
. . _ PMW-320K			X
. . _ PMW-300K2			X
. . _ PMW-300K1			X
. . _ PMW-200	X	X	
. . _ PMW-160	X	X	
. . _ PMW-150	X	X	
. . _ PMW-100	X	X	
. . _ PDW-F800			X
. . _ PDW-F355L			X
. . _ PDW-F335L			X
. . _ PDW-850			X
. . _ PDW-700			X
. . _ PDW-680			X
. . _ NEX-FS700EK	X	X	
. . _ NEX-FS700E	X	X	
. . _ NEX-FS100EK	X	X	
. . _ NEX-FS100E	X	X	
. . _ NEX-EA50		X	
. . _ HXR-NX70E	X		
. . _ HXR-NX5	X	X	
. . _ HXR-NX30E	X		
. . _ HXR-NX3	X	X	
. . _ HXR-MC50E	X	X	
. . _ HXR-MC2500		X	
. . _ HXC-D70L			X

run&gunBag Medium
run&gunBag Large
run&gunBag-XL

. . _ HXC-D70K			X
. . _ HXC-100			X
. . _ HVR-Z7E	X	X	
. . _ HVR-Z5E	X	X	
. . _ HVR-S270E		X	
. . _ HVR-HD1000E		X	
. . _ HDW-F900R			X
. . _ HDW-650P			X
. . _ HDC-3300R			X
. . _ HDC-2550			X
. . _ HDC-2500			X
. . _ HDC-2400			X
. . _ HDC-2000W			X
. . _ HDC-2000B			X
. . _ FDR-AX1	X	X	
. . _ F65			X
. . _ DVW-970P			X
. _ RED			
. . _ RED Scarlet	X	X	
. . _ Epic	X	X	
. _ Panasonic			
. . _ VariCam HS			X
. . _ VariCam 35			X
. . _ HC-X1000		X	
. . _ AK-HC931B			X
. . _ AK-HC3800			X
. . _ AK-HC3500			X
. . _ AJ-SDC615			X
. . _ AJ-PX800			X
. . _ AJ-PX5000			
. . _ AJ-PX270		X	
. . _ AJ-HPX3700			X
. . _ AJ-HPX2700			X
. . _ AJ-HPX2100			X
. . _ AJ-HDX900			X
. . _ AG-HVX200	X	X	
. . _ AG-HPX610			X



run&gunBags vs. cameras

run&gunBag Medium
run&gunBag Large
run&gunBag-XL

. . _ AG-HPX600			
. . _ AG-HPX500			X
. . _ AG-HPX370			X
. . _ AG-HPX3100			X
. . _ AG-HPX300			X
. . _ AG-HPX250	X	X	
. . _ AG-HPX2000			X
. . _ AG-HPX170	X	X	
. . _ AG-HMC80		X	
. . _ AG-HMC40	X		
. . _ AG-AF100	X	X	
. . _ AG-AC90			
. . _ AG-AC7		X	
. . _ AG-AC160	X	X	
. . _ AG-AC130	X	X	
. _ JVC			
. . _ GY-LS300	X		
. . _ GY-HMQ10U	X		
. . _ GY-HM890		X	
. . _ GY-HM850		X	
. . _ GY-HM790U		X	
. . _ GY-HM750U		X	
. . _ GY-HM700U		X	
. . _ GY-HM650U	X	X	
. . _ GY-HM600U	X	X	
. . _ GY-HM200	X		
. . _ GY-HM170	X		
. . _ GY-HM150U	X		
. _ Ikegami			
. . _ HK-399W			X
. . _ HK-399PW			X
. . _ Hi-Motion II			X
. . _ HDS-V10P			X
. . _ HDS-V10 /P /F			X
. . _ HDS-V10			X
. . _ HDN-X10			X
. . _ HDK-97A/AP			X
. . _ HDK-970A/AP			X

run&gunBag Medium
run&gunBag Large
run&gunBag-XL

. . _ HDK-79EX-III			X
. . _ HDK-79EC			X
. . _ HDK-790EX-III			X
. . _ HDK-77EC			X
. . _ HDK-727P			X
. . _ HDK-727			X
. . _ HDK-55			X
. . _ DNS-33W			X
. . _ DNS-201W			X
. _ Hitachi			
. . _ Z-HD5000			X
. . _ Z-4500W			X
. . _ SK-HD2200			X
. . _ SK-HD2000			X
. . _ SK-HD1200			X
. . _ SK-HD1000			X
. . _ HV-HD30			X
. . _ DK-Z50			X
. . _ DK-H32S10			X
. . _ DK-H32			X
. . _ DK-H200			X
. . _ DK-H100			X
. . _ CW-HD1000			X
. . _ CR-P2HD			X

run&gunBags vs. cameras

run&gunBag Medium
run&gunBag Large
run&gunBag-XL

	run&gunBag Medium	run&gunBag Large	run&gunBag-XL
. _ Canon			
. . _ XF305	X	X	
. . _ XF300	X	X	
. . _ XF205	X	X	
. . _ XF200	X	X	
. . _ XF105	X		
. . _ XF100	X		
. . _ XA25	X		
. . _ XA20	X		
. . _ XA10	X		
. . _ EOS C500		X	
. . _ EOS C300		X	
. . _ EOS C100	X	X	
. . _ EOS 1D C	X		
. _ Blackmagic Design			
. . _ URSA PL		X	X
. . _ URSA HDMI		X	X
. . _ URSA EF		X	X
. . _ URSA Broadcast		X	X
. . _ Studio Camera HD	X		
. . _ Studio Camera 4K	X		
. . _ Production Camera 4K	X		
. . _ Cinema Camera EF/MFT	X		
. _ ARRI			
. . _ Arriflex D-21			
. . _ Arriflex 765			
. . _ Arriflex 535 B			
. . _ Arriflex 435 Xtreme			
. . _ Arriflex 416/416 Plus			
. . _ Arriflex 416 Plus HS			
. . _ Arriflex 235			
. . _ Arricam Studio			
. . _ Arricam Lite			
. . _ AMIRA			X
. . _ Alexa STUDIO			X

run&gunBag Medium
run&gunBag Large
run&gunBag-XL

	run&gunBag Medium	run&gunBag Large	run&gunBag-XL
. . _ Alexa PLUS 4:3			X
. . _ Alexa PLUS			X
. . _ Alexa M			X
. . _ Alexa			X
. _ AJA			
. . _ CION		X	